



Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Suspension Solutions family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

Roadmaster Inc. 5602 NE Skyport Way Portland, OR 97218 1-800-669-9690 Fax: 503-288-8900
www.roadmasterinc.com

Class A Motorhomes									
Make	Model	Sub-Assembly	Year	Item #	Comments	Notes	Drilling	Time	Wt.
BEAVER	Santiam	8 Airbar Rear Radiator	05-09	1169-109	Rear sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator. RR8R chassis.		Yes	2.5	90
	Santiam	8 Airbar Rear Radiator	05-09	1169-110	Front sway bar 1 5/8 diameter for 8 air bag chassis rear radiator. RR8R chassis.		No	2.5	86
CHEVROLET/GMC	P Series	P30/P32/P3500	68-99	1109-116	Stage 1 susp. Kit. 1 5/8 diam. Front bar w/ poly bushing kit for 1 3/4 stock rear bar. Coil spring IFS (not for widebody).		No	1.5	51
	P Series	P30/P32/P3500	68-99	4109-109	Poly bushing kit for front 1 1/4 stock bar.		No	0.5	5.2
	P Series	P30/P32/P3500	68-99	4109-106	Poly bushing kit for rear 1 3/4 stock bar.		No	0.5	5
FORD	F53	Super Duty, V10 Engine	92-98	4139-127	Front poly bushing kit for OEM bar. 1 5/8 OEM bar.	3	No	0.5	3
	F53	Super Duty, V8 Engine	92-98	4139-127	Front poly bushing kit for OEM bar. 1 5/8 OEM bar.	3	No	0.5	3
	F53	Super Duty, V8 Engine	92-98	4139-125	Rear poly bushing kit for OEM bar - some endlink parts may not be used. 1 1/2 OEM bar.	3	No	1	3
	F53	TRITON F53 CHASSIS, V10 E	88-10	1139-143	1 1/2 AUX RR 2006 and on fits both GVWR 18,000 lbs over and under retains factory swaybar	52	Yes	2	85
	F53	Triton F53 Chassis, V10 Engine	98-05	1139-142	Auxiliary rear sway bar 1 1/2 diameter (used w/ stock sway bar) over 18,000 lbs. GVWR. Retains stock factory rear bar.	26,52	Yes	2	90
	F53	Triton F53 Chassis, V10 Engine	98-06	4139-125	Rear poly bushing kit for OEM bar - some endlink parts may not be used. 1 1/2 OEM bar.		No	1	3
F53	Triton F53 Chassis, V10 Engine	00-10	4139-300	Rear poly bushing kit for OEM bar - some endlink parts may not be used. 1 1/2 OEM bar.		No	1	3	

Class A Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
	F53	V8 and V-10 Engine	99-10	1139-140	1 3/4 Front factory replacement bar.		No	1	50
									Bar Replaces Factory Sway Bar
	FRED		07-08	1209-129	1 3/4" diameter factory replacement front swaybar.	61	No	1.5	54
									Bar Replaces Factory Sway Bar
	FRED		07-08	1209-130	1 1/2" diameter auxiliary rear swaybar.	61	Yes	2.5	89
	XC Chassis	Air Suspension Only	95-98	1209-105	Rear sway bar 1 1/2 diameter (for chassis w/ long 3/4 diameter u-bolts) most up to '98.	5,41	Yes	2.5	89
	XC Chassis	Air Suspension Only	99-03	1209-115	Rear sway bar 1 1/2 diameter (for chassis w/ short 7/8 diameter u-bolts) most '99-'03.	5,45	Yes	2.5	89
HOLIDAY RAMBLER	Ambassador	8 Airbar Rear Radiator	05-09	1169-109	Rear sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator. RR8R chassis.		Yes	2.5	90
	Ambassador, Endeavor, RR8R chassis	8 Airbar Rear Radiator	05-09	1169-110	Front sway bar 1 5/8 diameter for 8 air bag chassis rear radiator. RR8R chassis.		No	2.5	86
	Endeavor	8 Airbar Rear Radiator	02-04	1169-108	Front sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator. RR8R chassis.		No	2.5	86
	Endeavor	8 Airbar Rear Radiator	02-09	1169-109	Rear sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator. RR8R chassis.		Yes	2.5	90
	RR 8 R Chassis	8 Airbar Rear Radiator	02-04	1169-108	Front sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator. RR8R chassis.		No	2.5	86
	RR 8 R Chassis	8 Airbar Rear Radiator	02-09	1169-109	Rear sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator. RR8R chassis.		Yes	2.5	90
JOHN DEERE	John Deere		86-88	1169-144	1-5/8 diameter front sway bar		Yes	2.5	87
MONACO	Diplomat	8 Airbar Rear Radiator	02-09	1169-109	Rear sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator.		Yes	2.5	90
	Knight	8 Airbar Rear Radiator	05-09	1169-109	Rear sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator.		Yes	2.5	90
	LaPalma	Diesel Engine Only	05-10	1259-108	Rear sway bar 1.5 diameter.		Yes	3	112
	RR 8 R Chasis, Diplomat, Knight	8 Airbar Rear Radiator	05-09	1169-110	Front sway bar 1 5/8 diameter for 8 air bag chassis rear radiator.		No	2.5	86

Class A Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
	RR 8 R Chassis	8 Airbar Rear Radiator	02-04	1169-108	Front sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator.		No	2.5	86
	RR 8 R Chassis	8 Airbar Rear Radiator	02-09	1169-109	Rear sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator.		Yes	2.5	90
SPARTAN	MC 2000	Air Suspension Only	96-06	1149-125	Front sway bar 1 5/8 diameter.	37	Yes	2	74
	MC 2000	Air Suspension Only	96-03	1149-1055	Front sway bar 1 5/8 diameter (Holiday Rambler).		Yes	2.5	63
	MC 2000	Air Suspension Only	95-03	1149-106	Rear sway bar 1 5/8 diameter.	2, 58	No	2	81
	Verst Chassis		07-08	1149-121	Rear sway bar 1 1/2 diameter No bar connecting air bags. Jacks located to rear of cross member.	56	No	2	115
	Verst Chassis	Air Suspension Only	97-03	1149-118	Rear sway bar 1 1/2 diameter (late chassis) No bar connecting air bags.	39	No	2	104
	Verst Chassis	Air Suspension Only	04-06	1149-119	Rear sway bar 1 1/2 diameter (late chassis) No bar connecting air bags.	36	Yes	2	108
	Verst Chassis	Air Suspension Only	95-03	1149-106	Rear sway bar 1 5/8 diameter (early chassis) w/ solid bar connecting air bags.	2, 58	No	2	81
	Verst Chassis	Air Suspension Only	97-03	1149-118	Rear sway bar 1 1/2 diameter (late chassis) No bar connecting air bags.	35	No	2	104
	Verst Chassis	Air Suspension Only	04-06	1149-119	Rear sway bar 1 1/2 diameter (late chassis) No bar connecting air bags.	36	Yes	2	108
WORKHORSE	P Series		00-05	1109-200	Front sway bar stiffener; widetrack only.		No	1	25
	W Series Chassis	W16/W18	05-10	1259-115	Front sway bar 1 5/8 diameter.		Yes	2	87
	W Series Chassis	W16/W18	05-10	1259-118	Rear sway bar 1 1/2 diameter.	51	Yes	3	112
	W Series Chassis	W16/W18	05-10	1259-116	Combination front sway bar 1 5/8 diameter and front Trac Bar.		Yes	3.5	117
	W Series Chassis	W20, W22, W24	00-10	1259-105	Front sway bar 1 5/8 diameter.		Yes	2	87

Class A Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
	W Series Chassis	W20, W22, W24	00-10	1259-108	Rear sway bar 1.5 diameter.	47, 55	Yes	3	112
	W Series Chassis	W20, W22, W24	00-10	590054-00	Supplemental brackets for use when Ride Rite air bags are present. Welded application		No	2	10
	W Series Chassis	W20, W22, W24 Chassis	00-10	1259-106	Front sway bar 1 5/8 diameter. Front trac bar combination.		Yes	3.5	110

Class C Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
CHEVROLET/GMC	2500/3500	Van & Cut-away	04-10	1109-149	1 1/2 front factory replacement.		No	1.5	85
	2500/3500	Van & Cut-away	77-10	1109-150	1 3/8" diameter rear bar	68	No	1.5	43
	2500/3500	Van & Cut-away	77-10	1109-175	1 1/2" diameter rear bar	68	Yes	1.5	50
	C3500	Pickup Cab	88-98	1109-137	Front sway bar 1 3/8 diameter 2WD only.		No	1	32
	G30	Cut-away	75-96	1109-131	Front sway bar 1 3/8 diameter.		No	1	37
	G30	Cut-away	75-96	1109-121	Rear sway bar 1 1/4 diameter.		Yes	1.5	41
	G4500	Van & Cut-away	08-10	1109-149	1 1/2 front factory replacement		No	1.5	85
	G4500	Van & Cut-away	08-10	1109-150	1 3/8" diameter rear bar	68	No	1.5	43
	G4500	Van & Cut-away	08-10	1109-175	1 1/2" diameter rear bar	68	Yes	1.5	50
	Kodiak	4500, 5500	03-10	1109-158	Front sway bar 1 5/8 diameter.		No	2	52
	Kodiak	4500, 5500	03-10	1109-157	1 5/8 diameter rear facing rear auxillary bar	57, 59	No	2.5	55
DODGE	B250		75-03	1129-111	Rear sway bar 1 3/8 diameter.	15	Yes	1.5	48

Class C Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
	B350		75-03	1129-111	Rear sway bar 1 3/8 diameter.	15	Yes	1.5	48
	Sprinter	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter	63	No	1	25
									Bar Replaces Factory Sway Bar
	Sprinter	2500	08-09	1209-128	Rear swaybar 1 1/8 diameter factory replacement.		No	1	25
									Bar Replaces Factory Sway Bar
	Sprinter	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter	63	No	1	27
									Bar Replaces Factory Sway Bar
	Sprinter	3500	08-09	1209-120	1 3/8 diameter factory replacement	63	No	1	40
									Bar Replaces Factory Sway Bar
	Sprinter	3500	07-09	1209-131	Aux Rear Swaybar 1.5" diameter retains factory bar		Yes	2.5	60
	Sprinter	3500	04-06	1209-132	Aux Rear Swaybar 1.5" diameter retains factory bar		Yes	2.5	60
FORD	E250	Class C	92-10	1139-115	Front sway bar 1 3/8 diameter.	22	No	2	42
									Bar Replaces Factory Sway Bar
	E350		75-91	1139-100	Front sway bar 1 3/8 diameter.	18	No	1.5	37
	E350	Class C	92-10	1139-115	Front sway bar 1 3/8 diameter.	22	No	2	42
									Bar Replaces Factory Sway Bar
	E350	Class C	75-10	1139-117	Rear sway bar 1 1/2 diameter.	19	Yes	1.5	53
	E450	Super Duty	97-10	1139-115	Front sway bar 1 3/8 diameter.	22	No	2	42
									Bar Replaces Factory Sway Bar
	E450	Super Duty	97-10	1139-147	Rear sway bar 1 1/2 diameter.	27	Yes	1	47
									Bar Replaces Factory Sway Bar
FREIGHTLINER	Sprinter	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter	63	No	1	25
									Bar Replaces Factory Sway Bar
	Sprinter	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter	63	No	1	27
									Bar Replaces Factory Sway Bar
WORKHORSE	3500	Cut-away	07-10	1109-149	1 1/2 front factory replacement.		No	1.5	85

Class C Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
	3500	Cut-away	07-10	1109-150	1 3/8" diameter rear bar	68	No	1.5	43
	3500	Cut-away	07-10	1109-175	1 1/2" diameter rear bar	68	Yes	1.5	50

Emergency Vehicle Type 1

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
CHEVROLET/GMC	2500/3500	Van & Cut-away	04-10	1109-149	1 1/2 front factory replacement.		No	1.5	85
	2500/3500	Van & Cut-away	04-10	1109-150	1 3/8" diameter rear bar	68	No	1.5	43
	2500/3500	Van & Cut-away	04-10	1109-175	1 1/2" diameter rear bar	68	Yes	1.5	50
	C3500	Pickup Cab (except HD)	86-98	1109-137	Front sway bar 1 3/8 diameter 2WD only.		No	1	32
	G4500	Van & Cut-away	08-10	1109-149	1 1/2 front factory replacement		No	1.5	85
	G4500	Van & Cut-away	08-10	1109-150	1 3/8" diameter rear bar	65, 68	No	1.5	43
	G4500	Van & Cut-away	08-10	1109-173	1 1/2" diameter Rear factory replacment. Not for use with Auto-Chains.		No	1.5	
									Bar Replaces Factory Sway Bar
	G4500	Van & Cut-away	08-10	1109-175	1 1/2" diameter rear bar	65, 68	Yes	1.5	50
	Kodiak	4500, 5500	03-10	1109-158	Front sway bar 1 5/8 diameter.		No	2	52
	Kodiak	4500, 5500	03-10	1109-157	1 5/8 diameter rear facing rear auxillary bar	57, 59, 62	No	2.5	55
	Kodiak	4500, 5500	03-10	1109-174	FOR USE WITH GRANNING AIR RIDE ONLY! 1 5/8 diameter rear facing rear auxillary bar		No	2.5	60
DODGE	4500-5500	Chassis Cab	08-10	1129-131	Rear swaybar kit 1.5" diameter factory replacement.		No	2	
									Bar Replaces Factory Sway Bar
FORD	F350		05-08	1139-156	Front 1 3/8 diameter sway bar. 2WD ONLY. To replace factory bar		No	1	48
									Bar Replaces Factory Sway Bar

Emergency Vehicle Type 1

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
	F350	Cab Chassis	99-08	1139-160	Rear sway bar 1.5 diameter (to replace factory bar) round axle tubes. 2WD & 4WD	31	No	1	37
									Bar Replaces Factory Sway Bar
	F350	Cab Chassis	05-07	1139-157	Front sway bar 1 3/8 diameter. For coil spring only - 4WD only.	30	No	1	48
									Bar Replaces Factory Sway Bar
	F350	Cab Chassis	04-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only - 4WD only	30	No	1.5	48
									Bar Replaces Factory Sway Bar
	F350	Super Duty	08-10	1139-174	1 3/8" diameter factory replacement front swaybar super duty 4WD pickup and cab chassis SRW and dually.		No	1	45
									Bar Replaces Factory Sway Bar
	F450		99-06	1139-160	Cab chassis rear sway bar 1.5 diameter (to replace factory bar) Round axle tube	31	No	1	37
									Bar Replaces Factory Sway Bar
	F450		08-10	1139-171	Front bar 1.5 diameter 2WD & 4WD cab chassis F450-550		No	1	55
									Bar Replaces Factory Sway Bar
	F450		08-09	1139-161	Rear sway bar 1.5 diameter (to replace factory bar) square axle tubes	32	No	1	38
									Bar Replaces Factory Sway Bar
	F450	Super Duty Pickup Cab	86-98	1139-123	Rear sway bar 1 1/2 diameter w/ factory sway bar.	23	Yes	2	35
	F450	Cab Chassis	04-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only - 4WD only	30	No	1.5	48
									Bar Replaces Factory Sway Bar
	F550		00-08	1139-161	Rear sway bar 1.5 diameter (to replace factory bar) square axle tubes.	32	No	1	38
									Bar Replaces Factory Sway Bar
	F550		08-10	1139-171	Front bar 1.5 diameter 2WD & 4WD cab chassis F450-550		No	1	55
									Bar Replaces Factory Sway Bar
	F550	Cab Chassis	05-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only - 4WD only.	30	No	1	48
									Bar Replaces Factory Sway Bar
	F550	Cab Chassis	04-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only - 4WD only	30	No	1.5	48
									Bar Replaces Factory Sway Bar
	F650	Chassis Cab	09-10	1179-121	Front swaybar 1.5" diameter for Standard & LP Chassis 8,000lb & 10,000lb axle.		No	2.5	
	F650	Chassis Cab	09-10	1179-110	Rear sway bar 1 5/8 diameter (for trucks equipped w/ On Spot chains) Will work w/ air brakes. LIMITED GROUND CLEARANCE	67	Yes	2	90
FREIGHTLINER	FL Series	FL50, FL60	91-02	1209-100	Front sway bar 1 1/2 diameter - 8000 lbs. axle.	38	No	2	51

Emergency Vehicle Type 1

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
	FL Series	FL50, FL60	91-02	1209-101	Rear sway bar 1 1/2 diameter - Hendrickson air suspension only.	39	Yes	2.5	89
	FL Series	FL50, FL60	91-02	1209-104	Rear sway bar 1 1/2 diameter - Hendrickson air suspension w/ chains only.	40	Yes	2.5	89
	FL Series	FL50, FL60	91-02	1209-106	Rear sway bar 1 1/2 diameter - Airliner suspension (rear mount w/ chains). 5x4 u-bolt pattern.	42	Yes	2.5	90
	FL Series	FL50, FL60	91-02	1209-106S P	Onspot chains already on. Rear sway bar 1 1/2 diameter. Airliner 5x4 u-bolt pattern (rear mount).		Yes	2	90
	FL Series	FL50, FL60	91-02	1209-107	Rear sway bar 1 1/2 diameter - (front mount) Airliner w/o chains.	43	Yes	2.5	90
	FL70		91-02	1209-112	Rear sway bar 1 1/2 diameter - Hendrickson air only. With 6 x 4 u-bolt pattern.		Yes	2.5	89
	FL70		91-02	1209-113	Rear sway bar 1 1/2 diameter w/ 6x4 u-bolt pattern. With Airliner air suspension.	44	Yes	2.5	94
	M2		03-08	1209-106	Rear sway bar 1 1/2 diameter - Airliner suspension (rear mount w/ chains). 5x4 u-bolt pattern.	42	Yes	2.5	90
	M2		03-08	1209-106S P	Onspot chains already on. Rear sway bar 1 1/2 diameter. Airliner 5x4 u-bolt pattern (rear mount).		Yes	2	90
	M2		03-08	1209-107	Rear sway bar 1 1/2 diameter - (front mount) Airliner w/o chains.	43	Yes	2.5	90
	M2		03-08	1209-113	Rear sway bar 1 1/2 diameter w/ 6x4 u-bolt pattern. With Airliner air suspension.	44	Yes	2.5	94
	M2		03-08	1209-116	Front sway bar 1 1/2 diameter 8000lbs axle. Will not fit w/ Mercedes engine auxillary cooling package.	46	No	2	50
	Sterling		05-06	1209-119	Front sway bar 1 1/2 diameter		No	2	50
NAVISTAR/INTERNATIONAL	32/43/4400 Series		03-10	1179-110	Rear sway bar 1 5/8 diameter (for trucks equipped w/ On Spot chains) Will work w/ air brakes. LIMITED GROUND CLEARANCE.	67	Yes	2	90
	32/43/4400 SERIES Low Profile and Standard		09-10	1179-121	Front swaybar 1.5" diameter for LP Chassis 8,000lb & 10,000lb axle.		No	2.5	
	43/4400 Series		03-10	590060-00	Axle plate kit for applications without Onspot chains.		No		42
							Bar Replaces Factory Sway Bar		

Emergency Vehicle Type 1

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
	43/4400 Series	Won't fit LP	03-08	1179-108	Front sway bar 1 1/2 diameter 8,000 lbs axle. Will Not fit LP chassis		No	2	63
	43/4400 Series	Won't fit LP	03-08	1179-118	Front sway bar 1 1/2 diameter 10,000 lbs axle. Will Not Fit LP Chassis.		Yes	2	63
	4700 LP Series		89-02	1179-100	Front sway bar 1 1/2 diameter.		No	2	63
	4700 LP Series		89-02	1179-101	Rear sway bar 1 1/2 diameter w/ Navistar factory air ride only.		Yes	2.5	86
STERLING	4500-5500	Chassis Cab	08-10	1129-131	Rear swaybar kit 1.5" diameter factory replacement		No	2	
									Bar Replaces Factory Sway Bar

Emergency Vehicle Type 3

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
CHEVROLET/GMC	2500/3500	Van & Cut-away	04-10	1109-149	1 1/2 front factory replacement.		No	1.5	85
	2500/3500	Van & Cut-away	97-10	1109-150	1 3/8" diameter rear bar	68	No	1.5	43
	2500/3500	Van & Cut-away	97-10	1109-175	1 1/2" diameter rear bar	68	Yes	1.5	50
	G30	Cut-away	75-96	1109-131	Front sway bar 1 3/8 diameter.		No	1	37
	G30 Cut-away	Cut-away	75-96	1109-121	Rear sway bar 1 1/4 diameter.		Yes	1.5	41
	VAN	2500 & 3500	97-10	1109-148	Rear sway bar 1 diameter		Yes	1.5	30
	W4500	Cab Chassis	08-09	1109-172	Rear sway bar 1 1/2" diameter For Tilt Cab Chassis		No	2	80
DODGE	4500-5500	Chassis Cab	08-10	1129-134	1 5/8" diameter front factory replacment.		No	1	40
									Bar Replaces Factory Sway Bar
	B200	Cut-away	75-03	1129-111	Rear sway bar 1 3/8 diameter for cut-aways. Not for Sprinter.	15	Yes	1.5	48
	B300	Cut-away	75-03	1129-111	Rear sway bar 1 3/8 diameter for cut-aways. Not for Sprinter.	15	Yes	1.5	48

Emergency Vehicle Type 3

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
	E250	Cut-away	92-10	1139-115	Front sway bar 1 3/8 diameter.	22	No	1.5	42
									Bar Replaces Factory Sway Bar
	E350	Cut-away	75-91	1139-100	Front sway bar 1 3/8 diameter motorhomes cut-aways.	18	No	1.5	37
	E350	Cut-away	92-10	1139-115	Front sway bar 1 3/8 diameter.	22	No	1.5	42
									Bar Replaces Factory Sway Bar
	E350	Cut-away	75-10	1139-117	Rear sway bar 1 1/2 diameter motorhomes cut-aways.		Yes	1.5	53
	E350	Cut-away	75-09	1139-108	Rear sway bar 1 3/8 diameter (w/ automatic chains). Rear facing.	20	Yes	1.5	44
	E450	Super Duty	97-10	1139-115	Front sway bar: 1 3/8 diameter.	22	No	1.5	42
									Bar Replaces Factory Sway Bar
	E450	Super Duty	97-10	1139-147	Rear sway bar: 1 1/2 diameter.	27	Yes	1	47
									Bar Replaces Factory Sway Bar
STERLING	4500-5500	Chassis Cab	08-10	1129-134	1 5/8" diameter front factory replacment.		No	1	40
									Bar Replaces Factory Sway Bar

SUVs

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
CHEVROLET/GMC	Avalanche		00-08	1109-168	Rear sway bar 1 1/8 diameter (w/ factory bar).	48	No	1	36
									Bar Replaces Factory Sway Bar
	Escalade		00-08	1109-168	Rear sway bar 1 1/8 diameter (w/ factory bar).	48	No	1	36
									Bar Replaces Factory Sway Bar
	Suburban		92-99	1109-144	Rear sway bar 1 1/8 diameter (w/o factory bar).	11	No	1.5	34
	Suburban		92-99	1109-142	Rear sway bar 1 1/8 diameter (w/ factory bar).	10	No	1.5	23
									Bar Replaces Factory Sway Bar
	SUBURBAN		00-08	1109-168	Rear sway bar 1 1/8 diameter (w/ factory bar).	48	No	1	36
									Bar Replaces Factory Sway Bar
	Suburban	2500	00-08	1109-160	Rear sway bar 1 1/4 diameter (leaf spring suspension).	12	Yes	1	28
	Tahoe		95-99	1109-144	Rear sway bar 1 1/8 diameter (w/o factory bar).	11	No	1.5	34

SUVs

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
	Tahoe - Yukon		00-08	1109-168	Rear sway bar 1 1/8 diameter (w/ factory bar).	48	No	1	36
									Bar Replaces Factory Sway Bar
	Tahoe - Yukon		95-99	1109-142	Rear sway bar 1 1/8 diameter (w/ factory bar).	10	No	1.5	23
									Bar Replaces Factory Sway Bar
	Yukon		95-99	1109-144	Rear sway bar 1 1/8 diameter (w/o factory bar).	11	No	1.5	34
	Yukon	2500 XL	00-08	1109-160	Rear sway bar 1 1/4 diameter (leaf spring suspension).	12	Yes	1	28
DODGE	Durango		04-08	1129-126	1 Rear factory replacement bar.		No	0.5	40
									Bar Replaces Factory Sway Bar
FORD	Excursion		00-05	1139-155	Front sway bar 1 1/2 diameter	29	No	1.5	40
	Excursion		00-05	1139-154	Rear sway bar 1.375 diameter		Yes	1.5	45
	Expedition		97-03	1139-150	Rear sway bar 1 1/8 diameter		No	1	23
									Bar Replaces Factory Sway Bar
JEEP	Rubicon		04-08	1129-132	Rear swaybar 1 1/8" diameter factory replacment.		No	1.5	30
									Bar Replaces Factory Sway Bar

Vans & Pickups

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
CHEVROLET/GMC	2500/3500	Van & Cut-away	04-10	1109-149	1 1/2 front factory replacement.		No	1.5	85
	2500/3500	Van & Cut-away	04-10	1109-150	1 3/8" diameter rear bar	68	No	1.5	43
	2500/3500	Van & Cut-away	04-10	1109-175	1 1/2" diameter rear bar	68	Yes	1.5	50
	C/K 1500	Standard & HD	00-08	1109-167	Rear sway bar 1 1/4 diameter (2WD & 4WD)	13	Yes	1.5	40
	C/K 2500	Standard & HD	00-09	1109-167	Rear sway bar 1 1/4 diameter (2WD & 4WD)	13	Yes	1.5	40
	C/K 2500	Standard & HD	00-08	1109-166	Front Sway bar 1 1/2" diameter 2WD, 4WD, and Duallys, 2500, 3500 Factory replacement.		No	1	45
									Bar Replaces Factory Sway Bar

Vans & Pickups

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
	C/K 3500	Standard & HD	00-08	1109-166	Front Sway bar 1 1/2" diameter 2WD, 4WD, and Duallys, 2500, 3500 Factory replacement.		No	1	45
									Bar Replaces Factory Sway Bar
	C/K 3500	Standard & HD	08-08	1109-171	Rear sway bar 1 1/4 diameter SRW 4X4 and Dually.	8	No	1.5	47
	C/K3500	Standard & HD	00-07	1109-167	Rear sway bar 1 1/4 diameter (2WD, 4WD & dually)	13	Yes	1.5	40
	Silverado		00-08	590045-00	4 extended endlinks for vehicles with 4 lift kit installed		No	0.5	10
	Van	2500	97-10	1109-148	Rear sway bar 1 diameter.		Yes	1.5	30
	Van	3500	97-10	1109-148	Rear sway bar 1 diameter.		Yes	1.5	30
DODGE	3500	Pick-up Ram	96-02	1129-122	Rear sway bar 1 1/4 diameter 96-02 (4WD).	17	No	1.5	31
									Bar Replaces Factory Sway Bar
	3500	Pick-up Ram	07-09	1129-130	4X4, Dually and single rear wheel, 1 3/8" diameter rear swaybar		No	1.5	41
	1500	Pick-up Ram	09-10	1129-135	Rear sway bar 1 1/8" diameter factory replacment. 4X4 Only		No	1	25
									Bar Replaces Factory Sway Bar
	1500	Pick-up Ram	96-02	590053-00	Poly bushing kit for front factory bar		No	0.5	10
	2500	Pick-up Ram	96-02	1129-122	Rear sway bar 1 1/4 diameter 96-02 (4WD).	17	No	1.5	31
									Bar Replaces Factory Sway Bar
	2500	Pick-up Ram	03-08	1129-120	Rear sway bar 1 1/4 diameter 03-on (4WD) will fit single and dually.	16, 69	No	1.5	31
	2500	Pick-up Ram	96-02	590052-00	Poly bushing kit for front factory bar		No	0.5	10
	2500	Pick-up Ram	99-02	1129-136	1.5" diameter Front factory replacment.		No	1	40
									Bar Replaces Factory Sway Bar
	3500	Pick-up Ram	03-06	1129-120	Rear sway bar 1 1/4 diameter 03-on (4WD) will fit single and dually.	16, 69	No	1.5	31
	3500	Pick-up Ram	03-06	1129-137	Rear sway bar 1 1/4 diameter 03-06 (2WD) will fit single and dually.		Yes	1.5	31

Vans & Pickups

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
	3500	Pick-up Ram Dually 2WD	07-08	1129-133	Rear sway bar 1 3/8" for 2WD Dually pickup only.		No	1.5	80
	B200-300	Van	75-03	1129-107	Rear sway bar 1 diameter.	14	Yes	1.5	34
	B300	(conversion van only) 1 ton	75-03	1129-111	1 3/8 rear sway bar	15	Yes	1.5	48
	Sprinter	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter	63	No	1	25
									Bar Replaces Factory Sway Bar
	Sprinter	2500	08-09	1209-128	Rear swaybar 1 1/8 diameter factory replacement.		No	1	25
									Bar Replaces Factory Sway Bar
	Sprinter	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter	63	No	1	27
									Bar Replaces Factory Sway Bar
	Sprinter	3500	08-09	1209-120	1 3/8 diameter factory replacement	63	No	1	40
									Bar Replaces Factory Sway Bar
FORD	E250	VAN & PICK-UP	92-10	1139-115	Front sway bar: 1 3/8 diameter.	22	No	1.5	42
									Bar Replaces Factory Sway Bar
	E350	Van	75-06	1139-134	Rear sway bar 1 1/8 diameter for auto chains.	24	Yes	1.5	35
	E350	Van	75-06	1139-109	Rear sway bar 1 3/8 diameter.	21	Yes	1.5	51
	E350	VAN & PICK-UP	92-10	1139-115	Front sway bar: 1 3/8 diameter.	22	No	1.5	42
									Bar Replaces Factory Sway Bar
	F150		04-06	1139-152	1 1/8 rear bar. 4X4 only		No	1	48
	F150		09-10	1139-177	1 1/8" Diameter rear sway bar 2WD & 4WD.		Yes	1.5	40
	F250		99-03	1139-155	Front sway bar 1 1/2 diameter (4WD) 99-03.	29	No	1	40
	F250		99-03	1139-153	Rear sway bar 1 3/8 diameter F250 & F350 w/ factory bar only -99-03. No Dually.	28	No	1.5	34
									Bar Replaces Factory Sway Bar
	F250		99-07	1139-165	Rear sway bar 1 1/2 diameter F250 & F350 (dually).	33	No	1	29
									Bar Replaces Factory Sway Bar

Vans & Pickups

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
	F250		04-07	1139-170	Rear sway bar 1 1/2 diameter		No	1.5	49
									Bar Replaces Factory Sway Bar
	F250		04-07	1139-158	Front sway bar 1 3/8 diameter, coil spring only, 4x4 only		No	1	48
									Bar Replaces Factory Sway Bar
	F250		05-08	1139-156	Super Duty Front 1 3/8 diameter sway bar. 2WD ONLY. To replace factory bar		No	1	48
									Bar Replaces Factory Sway Bar
	F250	Super Duty	08-10	1139-174	1 3/8" diameter factory replacement front swaybar super duty 2WD & 4WD pickup and cab chassis SRW and dually.		No	1	45
									Bar Replaces Factory Sway Bar
	F350		04-07	1139-158	Front sway bar 1 3/8 diameter, coil spring only, 4x4 only		No	1	48
									Bar Replaces Factory Sway Bar
	F350		04-07	1139-170	Rear sway bar 1 1/2 diameter		No	1.5	49
									Bar Replaces Factory Sway Bar
	F350		99-07	1139-165	Rear sway bar 1 1/2 diameter F250 & F350 (dually).	33	No	1	29
									Bar Replaces Factory Sway Bar
	F350		99-03	1139-153	Rear sway bar 1 3/8 diameter F250 & F350 w/ factory bar only -99-03. No Dually.	28	No	1.5	34
									Bar Replaces Factory Sway Bar
	F350		99-03	1139-155	Front sway bar 1 1/2 diameter (4WD) 99-03.	29	No	1	40
	F350		05-08	1139-156	Super Duty Front 1 3/8 diameter sway bar. 2WD ONLY.To Replace factory bar		No	1	48
									Bar Replaces Factory Sway Bar
	F350		08-10	1139-173	Rear Swaybar 1 3/8 diameter factory replacment 4X4 and 2WD Must replace Factory Bar.	66	No	1.5	40
									Bar Replaces Factory Sway Bar
	F350	Super Duty	08-10	1139-174	1 3/8" diameter factory replacement front swaybar super duty 4WD pickup and cab chassis SRW and dually.		No	1	45
									Bar Replaces Factory Sway Bar
	F450		08	590055-00	Front and rear polyurethane bushings to replace factory rubber bushings		No	1	5
	F450		08-10	1139-171	Front bar 1.5 diameter 2WD & 4WD cab chassis F450-550		No	1	55
									Bar Replaces Factory Sway Bar
	F450		08-08	1139-175	Rear bar 1.5" diameter Fits 4WD SRW & Dually Pickups.		No	1.5	35
									Bar Replaces Factory Sway Bar
FREIGHTLINER	Sprinter	3500	08-09	1209-120	Rear Swaybar 1 3/8" diameter factory replacement.	63	No	1	40
									Bar Replaces Factory Sway Bar

Vans & Pickups

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
	Sprinter	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter	63	No	1	25
									Bar Replaces Factory Sway Bar
	Sprinter	2500	08-09	1209-128	Rear swaybar 1 1/8 diameter factory replacement.		No	1	25
									Bar Replaces Factory Sway Bar
	Sprinter	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter	63	No	1	27
									Bar Replaces Factory Sway Bar
NISSAN	Titan		07-07	1189-101	1 1/8 diameter rear sway bar		Yes	1	30
TOYOTA	Tundra		07-08	1189-102	5.7 liter V8 4x4. 1 rear sway bar		No	1	40

Application Guide Notes Key

- 1 · Modification may be required.
- 2 · Welding required.
- 3 · 1992 to mid-1995 have IPD-style bars with rubber bushings. Mid-1995 on have IPD-style bars with urethane bushings.
- 4 · 18,000 lbs. GVWR and under.
- 5 · Will not fit Newmar motorhomes.
- 6 · Not for Oshkosh X, V, M or T line chassis (check with manufacturer for your model using VIN#).
- 7 · 1991 and older require factory retro fit conversion kit.
- 8 · Will Work with air bags.
- 9 · With autochains and with and without air brake.
- 10 · Will fit 1992-99 models with 4WD. For vehicles with factory sway bar for Suburban and 4 door Tahoe/Yukon – not for 2 door models.
- 11 · Will fit 1999 models. For vehicles without factory bar. For Suburban and 4-door Tahoe/Yukon. Not for 2 door models.
- 12 · For 2000-on GMC Yukon XL and Chevy Suburban (leaf springs 2500/3500 series) not for “regular” Yukon or Tahoe (coil springs – 1500 series).
- 13 · For 2000-on Chevy/GMC 2500, 2500HD and 3500 (fits both single and dual rear wheels) pickups. Both gas and Duramax diesels. Will work with airbags.
- 14 · Fits 80-2003 ¾ ton and 1 ton vans.
- 15 · For 1975-03 Motor home chassis can be used on heavily loaded 1 ton vans.
- 16 · 2003-06 Dodge 4WD pickups 2500 and 3500 models, both single and dual rear wheels. For stock ride height vehicles. May not fit with 5th wheel hitch.
- 17 · 1996-02 4WD 2500 and 3500 pickups. Not designed for 2WD.
- 18 · For 1975-91 only. Not for E150.
- 19 · Fits 1975-2006 Motor homes and emergency vehicles. Will still work on 2005 gas E-series van cutaways.
- 20 · For E350 DRW (dual rear wheels/cutaway) chassis 1975-2003 with automatic chains. Nor for use on diesel or V-10 models.
- 21 · For 1975-2003 Ford E350 vans without chains. Type 2 Ambulance or Class B Motor home.
- 22 · 1992-2006 also fits E-Super Duty, sometimes called E450. This kit has offset endlinks for tie rod clearance. Does not fit E250 or E150.
- 23 · For 1988-91 F53 motor home chassis. Not for 1992 or newer motor homes. Also F450 pickup cab/chassis. 1986-97 to replace factory sway bar if not factory bar, additional parts will be needed (see Ford Dealer).
- 24 · For 1992 models and newer vans (Type 2 Ambulance/Class B Motor Homes) except Powerstroke diesels and V-10 models. The exhaust is in the way! Kit could be mounted if customer is willing to modify exhaust.
- 25 · For V-8 chassis and V-10 chassis with GVWR of 18,000lbs or less. The 4th digit of the VIN is L or M. GVWR is found on chassis data plate/sticker. These axle U-bolts are spaced 5” wide by 5.25” front to rear (Dana 80 axle). Will work with a tag axle if the drive axle has leaf springs.
- 26 · For 1998-on F53 with V-10 engine and GVWR greater than 18,000 lbs. The 4th digit of VIN is N. GVWR is found on chassis data plate/sticker. U-bolt spacing is 5” wide by 6.25” front to back (Dana S135 rear axle). Will work with a tag axle if the drive axle has leaf springs.
- 27 · Will work of the new 6 liter diesel engine for E450 chassis 1997-on. Mounts to axle same as factory bar and will work with chains. Replaces 1139-137. This bar has vertical forged ends.
- 28 · For 1999-2003 F250/350 pickup single rear wheels with factory sway bar (both 2WD and 4WD). Replaces factory bar. If no factory bar endlinks will be needed (#590230-00) need 1 per vehicle. Will not fit 2004 or any dual rear wheels. Bar mounts under differential, not over differential like stock sway bar.
- 29 · Front sway bar kit for 2000-04 Ford F250-F350 trucks with straight axle (all 4WD models and F450 with front leaf springs, and F550 2WD models). Replaces factory sway bar. Must have factory sway bar. Will not fit 2005-on with coil spring front suspension. Updated to exclude 1999 models. Will fit 1999 model when factory bar is present (added 1/2" hardware for 99 model year)
- 30 · Front sway bar kit for 2005-on Ford F450-F550 4WD trucks with coil spring axle. Replaces factory sway bar. Must have factory sway bar. Will only fit cabin chassis, not for pickups.

- 31 · Rear sway bar kit replaces factory sway bar. For F350 commercial cab/chassis (only Dana 80 rear end with shock bracket welded to axle). Will not fit any pickup. On F450 confirm Dana 80 axle (round axle tubes). If axle tubes are square (Dana 120) use kit #1139-161.
- 32 · Rear sway bar for 2000-08 F550 cab/chassis. Replaces factory bar. Also fits F450 with Dana 120 axle (square axle tubes).
- 33 · Rear sway bar for 1999-2007 F250 & F350 2WD and 4WD pickups with dual rear wheels and factory sway bar. Designed to replace factory sway bar. Not for lifted trucks.
- 34 · For chassis with true air brakes with air canister on the axle. Some chassis have air assist brakes or air over hydraulic brakes, these are not true air brakes.
- 35 · Rear sway bar kit for Spartan Verst, air suspension. 1996-on 1.5" diameter. Will not fit Renegade made by Harney Coach. Leveling jacks are in the way.
- 36 · For Spartan Verst air suspension. 2004-on.
- 37 · Fits Mountain Master M11 Verst Chassis.
- 38 · For FL series chassis with 8,000lbs front axle and 19.5" rims or 126" wheel height. Normally used on FL50 or FL60 series low profile trucks (most ambulance chassis). This will not work with the new Cat diesel engine introduced in 2000.
- 39 · For FL50 & FL60 ambulance chassis with Hendrickson air ride rear suspension. Will not work with chains (use 1209-104).
- 40 · For Freightliner FL50/FL60 chassis with automatic chains. Proven to fit with Onspot. Arms of bar face towards rear of truck for Hendrickson suspension only.
- 41 · For chassis up to 1998 and some 1999 and newer with long ¾" diameter. U-bolts on rear axle. Have customer or shop measure u-bolt diameter. For chassis with short 7/8" diameter U-bolts (most of 1999-on) use kit #1209-115. If rear suspension does not have U-bolts, we do not have a kit.
- 42 · For 2000-on FL50/FL60 Airliner chassis with Freightliner air suspension 10/12K-15K GVW. If truck has Hendrickson air rear suspension, use #1209-010 or #1209-104 with chains. Bar mounts towards rear of chassis. For use with autochains. Not for Class A motor homes.
- 43 · For FL series Airliner with Freightliner air suspension. Bar mount towards front of chassis. Not for use with chains. If vehicle is equipped with chains, use #1209-106.
- 44 · For Freightliner FL70 with Airliner rear suspension. Rear facing bar.
- 45 · For most 1999-2003 Freightliner XC. This kit is for chassis with short 7/8" diameter bolts on rear axle. NOTE: sometime in 2003 Freightliner suspension changed to a style with No U- bolts. Have customer/shop measure U-bolt diameter. For chassis with ¾" diameter U-bolts (mostly up to 1998) use kit #1209-105. If rear suspension does not have U-bolts (2003-on) we do not have a kit.
- 46 · Will not work on chassis with Mercedes Benz engines that have auxiliary cooling package, if standard cooling, it is okay.
- 47 · Update of kit #1259-106 now fits all years for Rear W22 Workhorse chassis. Also fits W20 chassis.
- 48 · Fits Chevy 1/2 ton SUV chassis, coil spring only.
- 49 · Will not fit with auto chains
- 50 · Only fits vehicles with gas tanks that are rear of the axle.
- 51 · Currently does not work with Super Hitch
- 52 · Check to insure there is enough factory ubolt available to accommodate the factory nut, washer and our ½" plate. If there is not enough ubolt the 590050-00 ubolt replacement kit is needed.
- 53 · If superhitch is installed the 590051-00 bracket kit is needed
- 54 · For use with Duramax diesel will not fit gas engine.
- 55 · When air bags have been added you will need the 590054-00 adapter kit which requires welding.
- 56 · For Spartan Mountain Master Verst air suspension chassis Tuthill 240AR with jacks located to the rear of the cross member.
- 57 · Will work with Kelderman air ride, Will work with Link Ultra ride.
- 58 · Chassis must have 3" square beam connecting the 2 airbags located underneath.
- 59 · Rear Leaf Spring hanger brackets may be bolted or riveted on. When riveted, install time will increase. Manufacture codes can be found under the driver side visor: EV8 = Rivets ; EV9 = Bolts.
- 60 · Will not work with air bags.
- 61 · Must have factory swaybars.
- 62 · When installing with Link UltraRide (2) B315 endlinks will be needed.
- 63 · 2007 Model year vehicles manufactured in or after June may have 2008 Chassis. Please confirm before ordering.
- 64 · Will work with other model years that have the inverted Y front steering system with factory dampener.
- 65 · Will work with automatic tire chains.

- 66 · When no factory bar is present, customer will need to purchase factory endlinks from Ford.
- 67 · For Applications Without onspot chains use 1179-110 and 590060-00.
- 68 · Chassis built before June of 2007 will require an additional axle mounting bracket kit part # 590061-00.
- 69 · Will NOT fit with Goose Neck Hitch.