



**Technical Service
Information Bulletin**
October 3, 2014

**Subject:
Time-saving tip
for wiring brake monitors**

If you're wiring a towed vehicle with: 1) separate brake and turn signals, and 2) the OEM brake light switch functions with the engine turned off, you can connect the monitor wire at the rear light assembly (see diagram below). This method works for InvisiBrake®, BrakeMaster™ and the 9700 monitor systems.

There are three advantages to this method: it eliminates the Brake-Lite Relay; there are no monitor connections under the dashboard; as a consequence of the first two advantages, you save time.

