




BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523192-5

05/18/17
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



Important
Note: this bracket will not accommodate the Guardian rock shield, some models of the Tow Defender, Stowaway or the StowMaster and StowMaster All Terrain tow bars.

ITEM	QTY	NAME	PART #
1.....6.....	6.....	1/2" x 1 1/4" BOLT	350094-00
2.....6.....	6.....	1/2" x 4 1/2" BOLT	350106-00
3.....10.....	10.....	1/2" NUT	350258-00
4.....4.....	4.....	1/2" FLAT WASHER	350308-00
5.....12.....	12.....	1/2" LOCK WASHER	350309-00
6.....2.....	2.....	1/2" TAB WELD NUT	350270-00
7.....2.....	2.....	1/2" PLATE WASHER.....	A-003086
8.....2.....	2.....	#10 x 3/4" SELF DRILLING SCREW.....	350247-35
9.....1.....	1.....	WIRE PLUG PLATE	A-003801
10.....1.....	1.....	DRIVER SIDE REAR BRACKET.....	B-003300
11.....1.....	1.....	PASSENGER SIDE REAR BRACKET	B-003301
12.....1.....	1.....	DRIVER SIDE ARM.....	C-002383
13.....1.....	1.....	PASSENGER SIDE ARM	C-002384
14.....1.....	1.....	MAIN RECEIVER BRACE.....	C-003163
15.....1.....	1.....	ZIP TIE.....	300140-8



BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523192-5

05/18/17
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com

This is one of our EZ5 Twistlock series brackets, which allows the visible front portion of the bracket to be easily removed from the front of the vehicle (Fig.A and Fig.B).

The bracket mounts to the frame of the vehicle and consists of a main receiver brace, two rear support braces, two removable front braces, and a hardware pack.

Before starting the installation, lay out the kit components in order, as they will be used. This will give you a visual idea of how the components work, and will also confirm that everything is present and accounted for.



IMPORTANT: All baseplates **must** be assembled with all the bolts left loose for final adjustment and positioning (before tightening) unless otherwise instructed. All bolts **must** be torqued for proper strength. If more than one bolt is used per fastening point, the diagram may only show one. Use flat washers over all slotted holes and lock washers on all fasteners.

WARNING

Failure to heed these warnings or follow the installation instructions may result in a voided warranty, loss of towed vehicle, personal injury or death.

- Do not weld or modify this baseplate or its components. Welding or modification will void the warranty.
- Do not use this document as a basis to design/fabricate a baseplate, as it may not show all parts or structural components.
- We strongly recommend professional installation.
- If the towed vehicle has been in an accident, it must be properly repaired before attaching the baseplate. Do not install the baseplate if any structural frame damage is found.
- The installer must use all bolts and parts supplied. If running changes were made by the vehicle manufacturer after this kit was designed, some bolts or other fasteners may no longer be the correct size. It is the installer's responsibility to verify this kit is securely fastened to the vehicle.
- Use Loctite® Red on all bolts used to secure this baseplate. Torque all bolts to the specifications found at the end of these instructions. Do not over-torque the bolts or failure may occur.
- The installer must inspect the baseplate to ensure adequate clearance, particularly around hoses, air conditioner lines, radiators, etc. or non-warranty failure may result.
- Roadmaster manufactures many styles of baseplates. If your baseplate has removable arms, they must be removed before driving the vehicle, unless the arms can be pinned or padlocked in place. If not secured, the arms could vibrate out.
- Some motorhome chassis have such a tight turning radius that you can damage your motorhome, towed vehicle, tow bar or baseplate while turning sharply. Before getting on the road, test your turning radius in an empty parking lot. Turning too sharply could result in non-warranty damage to your towing system, motorhome and/or towed vehicle.
- Do not back up with the towed vehicle attached or non-warranty damage will occur to your towing system or vehicles.
- The safety cables must connect the towing vehicle to the towed vehicle frame to frame, with the cables crossed, with enough slack for sharp turns. See cable instructions for proper routing. Failure to do so will result in non-warranty damage and/or the loss of the towed vehicle.
- This kit is designed for use with ROADMASTER tow bars and ROADMASTER adapters only. Using this kit with other brands, without an approved ROADMASTER adapter, may result in non-warranty damage or injury.
- Receiver extensions and out-of-level towing situations of 3 inches or more. This can cause the system to swing much higher and lower, causing excessive strain on the tow bar, baseplate and frame. That can cause the towing system to fail, causing property damage, personal injury or even death. If you must use a receiver extension or drop hitch to tow, it will reduce your receiver's weight capacity by 1/3 to avoid damaging your system. Never use more than one extension and/or drop hitch, as this will void your warranty.
- Every 3,000 miles, the owner must inspect all mounting points for cracks or fatigue, and check the fasteners for proper torque, according to the bolt torque requirements chart on the last page of these instructions.
- The owner must follow the vehicle manufacturer's instructions to prepare the vehicle for towing. Failure to do so may cause severe damage to the vehicle.
- This baseplate is only warranted for the original installation. Installing a used baseplate on another vehicle is not recommended and will void the warranty.




BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523192-5



05/18/17
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com





1. **Important:** please use all supplied bolts and parts and read all instructions carefully before beginning this installation. The majority of questions you may have can be answered within the text, and proper installation will ensure safe and secure travel. Now, on each side, remove six 10mm (head) bolts and six plastic fasteners attaching the top of the fascia to the core support (Fig.C).

2. On each side, remove three T20 Torx screws attaching the fender liner to the fascia (Fig.D). Pull the fender liner out and remove the T20 Torx screw attaching the fascia to the fender (Fig.E).



3. Disconnect the lower splash shield from the core support and fascia by removing two 13mm (head) bolts, one plastic fastener and two T20 Torx screws (Fig.F).

4. On each side, remove the bracket attaching the core support to the fascia by removing four T20 Torx screws and one Philips screw attaching the fender liner to the fascia and the lower splash shield to the core support (Fig.G and H).





BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523192-5

05/18/17
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



Fig.I




Fig.J

5. Pull out on the corners of the fascia to remove it (Fig.I). Disconnect all electrical connectors, fog lights and ambient temperature sensor.

6. On each side, trim the air dam (Fig.J) and radiator bracket (Fig.K).




Fig.K




Fig.L

7. On each side, on the front mount, bolt the rear support brace to the bumper core using two $\frac{1}{2}$ " x $4\frac{1}{2}$ " bolts, and $\frac{1}{2}$ " flat washer, and finish with a $\frac{1}{2}$ " lock washer and $\frac{1}{2}$ " nut. On the rear mount, use a $\frac{1}{2}$ " x $4\frac{1}{2}$ " bolt, $\frac{1}{2}$ " lock washer, and $\frac{1}{2}$ " flat washer and finish with a tab weld nut (Fig.L). Use the drawing on page 1 as a reference to ensure that each side-specific brace is used correctly.

8. On each side, loosen three 13mm (head) bolts attaching the lower bumper to the frame (Fig.M). Loosen it so it hangs down slightly.



Fig.M



BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523192-5


05/18/17
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



9. Place the main receiver brace between the rear support braces and on each side, bolt the rear support brace to the main receiver brace using the supplied $\frac{1}{2}$ " x $1\frac{1}{4}$ " bolts, $\frac{1}{2}$ " lock washers and $\frac{1}{2}$ " nuts (Fig.N).

10. On each side, use the existing hole in the rear support brace as a template to drill through the frame (Fig.O). *Note:* ensure that the drill is level. Then, bolt through the hole using the supplied $\frac{1}{2}$ " x $4\frac{1}{2}$ " bolt, and $\frac{1}{2}$ " plate washer, lock washer and nut (Fig.P).



11. Torque all bolts to the bolt torque specifications found at the end of these instructions. *Note:* use Loctite® Red on all nuts and bolts.

12. On each side, trim the fascia as shown in Figure Q.



BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523192-5



05/18/17
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com



13. **Note: the following four images are for illustration purposes only, as your specific application may be slightly different.**

The spring-loaded pin on the removable arm snaps into a notch on the receiver, locking the removable arm into its final towing position. Before inserting each arm into the receiver, verify that the spring is working by ensuring that the spring-loaded pin moves easily back and forth within the barrel when pulled and that it can be pulled flush with the face of the barrel (Fig.R and Fig.S).



14. On each side, insert the removable front bracket arm into the front receiver 90 degrees from its final towing position, depressing the spring-loaded pin against the receiver (Fig.T). Now, twist back 90 degrees until the spring-loaded pin snaps into place in the notch on the receiver, locking the arm into place in its final towing position (Fig.U).

Please note: it is the owner's responsibility to ensure the locking of the pins before towing. Otherwise, failure of the towing system will result.

15. Install the tow bar to the mounting bracket according to the manufacturer's instructions.



BASEPLATE KIT INSTALLATION INSTRUCTIONS

KIT# 523192-5


05/18/17
KS

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 360-896-0407 fax 360-735-9300 www.roadmasterinc.com

IMPORTANT!

Safety cables are required by law. When towing, connect safety cables to the safety cable tabs shown in Figure V. Make certain there is adequate slack in the cables to allow a full turning radius; otherwise, damage will result. If necessary, longer cables or cable extensions are available.

Note: if the bracket is so equipped, the holes in the alignment tabs which are welded to the arms and main receiver braces are for padlocks only. Under no circumstances should you bolt the alignment tabs together. Bolting the alignment tabs together may result in non-warranty damage to the bracket.




Three options for attaching the wiring plug to the main receiver brace

For six-wire plugs: use the two supplied 3/4" self-tapping screws to attach the electrical plug directly to the rods on the front of the main receiver brace.

For four-wire round plugs: attach to the plug mounting plate and then use the two supplied 3/4" self-tapping screws to attach the mounting plate to the rods on the front of the main receiver brace.

For four-wire flat plugs: place the plug through the mounting plug plate, and then secure it using the supplied zip tie on the front of the plug (Fig.W). Use the two supplied 3/4" self-tapping screws to attach the mounting plate to the rods on the front of the main receiver brace.



BOLT TORQUE REQUIREMENTS

Note: The torque values represented below are intended as general guidelines. Torque requirements for specific applications may vary. Roadmaster does not warrant this information to be accurate for all applications and disclaims all liability for any claims or damages which may result from its use.

STANDARD BOLTS

Thread Size	Grade	Torque
5/16-18	5	13 ft./lb.
3/8-16	5	23 ft./lb.
7/16-14	5	37 ft./lb.
1/2-13	5	57 ft./lb.
5/8-11	5	112 ft./lb.

METRIC BOLTS

Thread Size	Grade	Torque
6mm-1.0	8.8	6 ft./lb.
8mm-1.0	8.8	18 ft./lb.
8mm-1.25	8.8	16 ft./lb.
10mm-1.25	8.8	36 ft./lb.
10mm-1.5	8.8	31 ft./lb.

METRIC BOLTS

Thread Size	Grade	Torque
12mm-1.25	8.8	64 ft./lb.
12mm-1.5	8.8	60 ft./lb.
12mm-1.75	8.8	55 ft./lb.
14mm-2.0	8.8	88 ft./lb.

All illustrations and specifications contained herein are based on the latest information available at the time of publication approval. ROADMASTER, INC. reserves the right to make changes at any time without notice in material, specification and models or to discontinue models.